

# Porch



IF YOUR NORDIC TIPI DOES NOT HAVE A PORCH SLEEVE, YOU MUST FIRST ATTACH THE SEPARATE PORCH CONNECTOR.



ATTACH THE PORCH CONNECTOR TO THE TOP, AROUND THE BAND WHICH HOLDS THE CAP AND VENTILATOR CAP TOGETHER.



NAIL THE LONG BANDS TO THE GROUND.



TIGHTEN THE BANDS, ENSURING THAT THE PORCH CONNECTOR IS CORRECTLY AND SNUGLY POSITIONED.



POSITION TWO TENT PEGS 35 - 40 CM FROM THE DOOR. USE THE MEASURING CORD TO GET THE RIGHT DISTANCE BETWEEN THE PEGS.



USING THE VELCRO FASTENING, ATTACH THE PORCH UNDER THE PORCH CONNECTOR/PORCH SLEEVE.



ATTACH THE STRAPS TO THE NORDIC TIPI'S STORM CORD FASTENINGS. TIGHTEN THE STRAPS.



PUSH THE POLE INTO ITS CHANNEL.



PLACE THE ENDS OF THE POLE INTO THEIR RESPECTIVE POLE POCKETS. ADJUST THE STRAP ON THE INSIDE.



SECURE THE ARCHED POLE TO THE GROUND USING THE TWO TENT PEGS ALREADY IN PLACE.



STRETCH THE PORCH AND NAIL IT TO THE GROUND. IF YOU WANT TO REMOVE THE PORCH DOOR, NAIL DOWN THE STORM CORDS TOO.