

Central pole



Handle your central pole with care. Stretch the ground straps equally around the tent; 15 kilos of strain on each ground strap is sufficient. Over-stretching may cause the central pole to bend.

If for some reason, the central pole has become bent, it must not be used. A bend on the pole means the pole has been weakened and this may lead to the pole breaking and the Nordic tipi collapsing. If this should happen when a fire or stove is in use inside the tent, this could cause great damage and people could be seriously injured.